



NOTEBOOK COOLER USER GUIDE

N9



www.deepcoolglobal.com

Pre-Use Note

1. Check the product condition before use. In case of any problem, please contact your retailer.
2. To ensure product lifespan, please do not use on uneven or vibrating surfaces.
3. To ensure fan performance, please do not interrupt the air inlets or obstruct the fan rotation.
4. All specifications subject to change without notice.
5. Under no condition shall Deepcool be liable for any indirect, incidental or consequential damages arising from any defect or error in this manual or product.
6. For more information for this product, please visit our website: www.deepcoolglobal.com.


Specifications

Overall Dimension	380X279X34mm
Fan Dimension	Ø180X15mm
Weight	1700g
Rated Voltage	5VDC
Operating Voltage	4.5~5VDC
Rated Current	0.12±10%~0.22±10%A
Power Input	0.6~1.1W
Fan Speed	600±10%~1000±10%RPM
Max. Air Flow	84.7CFM
Noise Level	16~20dB(A)
Bearing Type	Hydro Bearing


Components List



Features



How to Use



- ① Connect N9 with Notebook using the USB power cable.
- ② Put the Anti-slip buckle into the groove on the front panel, and slide them into proper width to suit your Notebook.
- ③ Fan power / Speed control: Turn the knob in clockwise direction to switch on the fan and adjust the fan speed accordingly. And turn the knob in anticlockwise direction to switch off the fan.
- ④ Output ports: Please connect your USB devices using these ports.
- ⑤ Angle adjustable: Put the metal supporting feet into the groove which offers the most comfort for your use. The angle degrees are: 12°/24°/33°/40°/45°.

Appearance Patent NO. : 201230027307.2

Brands and designs are trademarks from Beijing Deepcool Industries Co., Ltd.
All rights reserved.

Beijing Deepcool Industries Co., Ltd.

MADE IN CHINA